

TIME SAVING REUSEABLE DEPENDABLE



PMA CERTIFICATION VOID WITHOUT THIS INSTRUCTION CARD.

6 RG-17727

VALVE COVER GASKET

**FAA-PMA FOR FRANKLIN ENGINE MODELS:
6A-350; 4A-235; 6A4-150-B3, -B4, -B5, -B6;
6A4-165-B3, B4, B6;
6A4-200-C6; 6AS-350; 6AS-335.
WITH STC SE3331NM INSTALLED**

INSTALLATION AND MAINTENANCE PROCEDURE

1. Remove the valve cover and gasket in accordance with the franklin procedure or in accordance with an acceptable procedure used by the shop performing the installation.
2. Clean the valve cover and the cylinder surfaces of all residual material.
3. Install gaskets, DRY.
4. Replace the valve cover and torque the cover bolts to 25 in-lbs.
5. Check the cover bolt torque after an engine run-up to take off power or first flight and re-torque the bolts to 20 in-lbs.
6. Check the cover bolt torque annually, and re-torque to 20 in-lbs, if necessary.

The gaskets are re-usable and the service life of the gasket is determined by its physical condition on removal. If the gasket is still pliable and without cracks, tears, or deterioration, it may be re-used, otherwise discard.

THE GASKET SURFACES MUST BE CLEAN AND DRY

****CAUTION****

DO NOT OVERTIGHTEN

REPORT ALL SERVICE DIFFICULTIES PERTAINING TO THIS PRODUCT TO:

REAL GASKETS TENNESSEE

2506 Stateline Road, Elizabethton, TN 37643 USA

PH 800-635-7325 423-543-6194

Fax 423-543-9772

e-mail: parts-sales@realgaskets.com

www.realgaskets.com

DOC: RG-17727

REVISION: III

DATE: 05/30/2014